

morphyrichards


Juicer mixer grinder

Divo

The Star



Please read and keep these instructions



5 year
guarantee
on
MOTOR

2 year
guarantee
7 años de garantía (2 años de garantía)



Getting the best from your
new juicer mixer grinder..

www.morphyrichards.co.uk
www.morphyrichardsindia.com

Important Safety Instructions

The use of any electrical appliance requires the following of basic common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance!

In addition we offer the following essential safety particularly when unsupervised and if advice.

Location

- Do not use outdoors.

Mains lead

- The mains lead should reach without straining the connections.
- Do not let the mains lead hang over the edge of a worktop where a child could reach it.
- Do not let the lead run across an open space e.g. between a low socket and table.
- Do not let the lead run across a cooker or toaster or other hot area which might damage the cable.

Your safety

- Keep the Juicer Mixer Grinder at least 6" (150mm) away from the wall.
- Have sufficient place around the Juicer Mixer Grinder to keep the various items and ingredients required.
- Don't touch moving parts & blades when the Juicer Mixer Grinder is in operation.
- To protect against electrical hazards, do not immerse any part of the Juicer Mixer

Grinder like base, plug or cord in water or any other liquids.

- Never operate your Juicer Mixer Grinder without lid and lid cap.
- Never operate your Juicer Mixer Grinder unless there is load in the jar.
- Do not pull the cord to disconnect, instead grasp the plug and pull to disconnect.
- Always disconnect the plug from the power outlet before cleaning, while emptying and when not in use.
- Do not let the power cord hang over the edge of table/counter or touch any hot surface. If the plug or cord is damaged, do not use the appliance.
- In the event of any failure of your Juicer Mixer Grinder, do not attempt to repair it at home or allow any unauthorised person to do so. Ensure repairs are carried out only at an authorised Morphy Richards Centre.

Children

- Do not allow children to use this Juicer Mixer Grinder. Children are vulnerable in the kitchen particularly when unsupervised and if appliances are being used or cooking is being carried out.
- Teach children to be aware of danger in the kitchen, warn them of the dangers of reaching up to areas where they cannot see properly or should not be reaching.

Other safety considerations

- To protect against fire, electric shock and personal injury do not immerse cord, plug or body in water or other liquid.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended

by the manufacturer as there is the danger of fire, electric shock or personal injury.

- Do not place on or near a hot gas or electric burner or in a heated oven.


Electrical requirements

- Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be

A.C. (Alternating Current).

- If the socket outlets in your home are not suitable for the plug supplied with this appliance, the plug should be removed and the appropriate one fitted.

WARNING: The plug removed from the mains lead, if severed, must be destroyed as a plug with bared flexible cord is hazardous if engaged into a live socket outlet.



Features

- 1 Feeder Opening
- 2 Juicer Housing
- 3 Spout Cover
- 4 Juicer Mesh
- 5 Plunger
- 6 Rotary Switches
- 7 Cleaning Brush
- 8 Spatula
- 9 Pulp Container
- 10 Lid Cap
- 11 Jar Lid

- 12 Dry/Wet Grinding Jar
- 13 Liquidising Jar
- 14 Chutney Grinding Jar
- 15 Jar Rubber Gasket
- 16 Grinding Blade
- 17 Liquidising Blade
- 18 Whipping Blade
- 19 Mincing Blade
- 20 Chutney Grinding Blade

Unpacking your Juicer Mixer Grinder

Carefully unpack your Juicer Mixer Grinder, as blades are very sharp.




Assembly

WARNING: Make sure that the juicer mixer grinder is switched off and unplugged.


- 1 Clean the juicer mixer grinder attachments before using it for the first time with damp cloth.
- 2 Insert the juicer mixer grinder blades into the appropriate jar and turn until it locks into position.

How to use the juicer

- Place juicer housing and the pulp container on the basic unit. Put spout cover in position. Place glass or bowl under spout (Fig. 2).
- Place filter mesh into the housing and push down slightly so that the mesh fits and locks properly on the lower coupler of the motor housing. Rotate the mesh a little to see that it fits properly. (Fig. 3).
- Place top cover onto juicer housing and lock side clamps (Fig. 4).
- Wash and cut ingredients to fit in feeder opening.




- Plug in. Push the switch button No. 1. Push ingredients into the feeder with the help of the plunger (Fig. 5).



- At the end of the operation, switch off the Juicer-Mixer-Grinder and unplug.




Caution:

- Do not use fruits such as Bananas & peaches which produce a thick paste that can clog the filter mesh.
- Remove pulp from the pulp container whenever it is full. Stop machine before removing pulp container. (Fig. 6).



How to use the mixer / grinder

- Place ingredients in liquidising / grinding / chutney jar and put lid in position. Place jar on basic unit and turn the jar.
- Place ingredients in liquidising / grinding / chutney jar and put lid in position. Place jar on basic unit and turn the jar.
- Switch off after liquidising / grinding. Unplug. Unlock and lift the jar from the basic




Motor overload protection

The juicer mixer grinder is fitted with a heavy duty universal motor using a winding wire that can withstand extremes of temperatures.

Therefore, the chances of motor failure are extremely rare.

It is however possible that the mixer motor may get overloaded when you attempt to grind quantities in excess of normal.

The motor of the Juicer-Mixer-Grinder is protected by a resetting type Over Load Protector (OLP). In case of overloading, the OLP disconnects the power supply to the motor. In such an eventuality, switch off the supply. Remove the excess load or add water to the ingredients, if the recipe so permits. Wait for a few minutes. Reset the OLP located below the base plate and restart the mixer. (Fig. 10).




Care & Cleaning

Cleaning of the Juicer

To clean the filter mesh, fill cleaning bottle with soap water, fit brush onto bottle and insert in mesh cleaning shutter. Switch on by pushing button (I) Ensure that a glass or bottle is kept under the spout to collect the dirty water.

Move brush up & down across the juicer mesh while squeezing bottle to squirt water from brush (Fig. 11).



Cleaning of the Mixer & Grinder Jars

After each use it is desirable to wash and thoroughly clean the jars.

For cleaning, fill up the jar with water up to half its capacity. A small quantity of detergent or liquid soap will help clean better, especially after use with sticky or oily foods. Fix the jar on the mixer-grinder base and run for about 15 to 20 seconds. The blade rotating at high speed in water, will clean the jar thoroughly and remove all food material stock on the blade assembly. Do not use scouring powder to clean the jars as it would leave marks. To remove traces of water from the blade assembly, run the mixer-grinder with the empty jar for 10 seconds.

Clean the jar lid with a dry cloth to avoid unpleasant odour when the mixer is taken up for use again.

Do not wash the base unit or immerse it in water as it could cause electrical hazards. Wipe the base unit clean with a damp cloth to remove stains, if any and then wipe with a dry cloth to keep the base unit dry and clean.

Technical Data

Power Supply : AC 230V 50Hz

Wattage : 500W

Morphy Richards products are intended for household use only

Morphy Richards has a policy of continuous improvement in product quality and design. The Company, therefore, reserves the right to change the specification of its models at any time.

Products & parts are indicative only, the actual product may differ.

morphy richards

Morphy Richards Ltd, Mexborough,
South Yorkshire, England, S64 8AJ