


morphyrichards

Electric Cooker/ Steamer S701EGT



Please read and keep these instructions



getting the best from
your new electric cooker / steamer



www.morphyrichards.co.uk
www.morphyrichardsindia.com

Technical Data

• Power Supply : 230V AC 50Hz

• Wattage : 700W

Important Safeguards

1. Read all instructions before using this appliance.
2. The use of any electrical appliance requires knowledge of following safety rules.
3. Primarily there is danger of personal injury and secondly danger of damage to the appliance and property. These are indicated in the instructions text below:

Your Safety

1. Do not touch hot surfaces. Use oven gloves or a cloth when removing lid or handling hot containers .
2. To protect against fire, electric shock and personal injury do not immerse cord, plugs, or appliance in water or other liquids.
3. Unplug from the socket when not in use, before putting on or taking off attachment, and before cleaning.
4. Do not operate any appliance with a damaged lead or plug, or after an appliance has malfunctioned, or has been dropped or damaged in any way.
5. Always use heat resistant gloves to remove the inner bowl and lid from the cooker.

Never allow a child to operate this appliance. Teach children to be aware of dangers in the kitchen, warn them of the dangers of reaching up to areas where they cannot see properly or should not be reaching.

Location

1. Ensure that this appliance is situated out of the reach of children.
2. Do not place directly under kitchen wall cupboards when in use as it produces large amounts of steam. Avoid reaching over the steamer when in use.
3. Do not use outdoors.

Mains Lead

1. The mains lead should reach from the socket to the base unit without straining the connections.
2. Do not let the cord hang over the edge of the table or the counter and keep it away from any hot surfaces.
3. Do not let the lead run across an open space e.g. Between a low socket and table.

Other Safety

Considerations

1. The use of attachments or tools not recommended by Morphy Richards may cause fire, electric shock or injury.
2. Extreme caution must be taken when moving the cooker, when it contains hot food, water, or other liquids.
3. To open, lift the lid off towards yourself but tilted away from you.
4. Do not use any parts of this product in a microwave or on any cooking/heated surfaces.
5. Do not place on or near a hot gas or electric burner, or in a heated oven.
6. Do not wash rice in the cooking pan as it may damage the non-stick coating and may deform, which will affect the cooking process.
7. Never use the cooker to boil acid or alkaline foodstuff. Do not leave it in a damp

or corrosive environment.

8. Do not reheat cooked rice in the cooker.
9. The use of sharp implements inside the cooking pan may damage the non-stick coating.

Worth Noting

If your cooker dose not work, check the following points:

1. Is the plug in its socket and the switch in the 'ON' position?
2. Is the plug itself or the socket faulty - check this by plugging in another appliance.
3. In the unlikely event that the power cord requires replacement or your cooker needs repairs, than do not attempt these tasks

Electrical Requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C.(Alternating Current).

If the socket outlets in your home are not suitable for the plug supplied with this appliance, the plug should be removed and the appropriate one fitted.

WARNING: The plug removed from the power cord, if severed, must be destroyed as a plug with bared flexible cord is hazardous if engaged into a live socket outlet.

WARNING:This appliance must be earthed.

Description of parts

1. Main unit
2. Cooking pan
3. Steamer
4. Lid
5. On/off switch
6. Cooking indicator
7. Keep warm indicator
8. Soup indicator
9. Power socket (at side)
10. Measuring cup
- 11.Spatula


Before Use

Before using your cooker for the first time, wash and dry the bowl, steamer and lid.

Assembly

- Use the Steamer only when steaming.
- Be sure to keep the space between the cooking pan and the heating plate clean

Parts diagram



yourself, but contact Morphy Richards Service Center.

Save These Instructions

and free of water drops, dust, rice grains or any other foreign matter. If not, the cooker's performance will be affected and possibly the element could burn out.

- Place the cooker on a stable and flat surface otherwise the bottom of cooking pan will not be in full contact with the heating plate and the element may burn out.

Do not switch ON power until ready to cook.

Cooking rice

1. Use the measuring beaker provided to measure the rice, filling level to the top. As a guide, one cup of rice is sufficient for one person, but this will vary according to individual requirement.

2. Thoroughly wash the rice in several changes of water and drain. Failure to do so may cause poor results and/or a build-up of steam within the cooker. Do not wash the rice in the cooking pan as it may damage the non stick coating.

3. Transfer the rice to the cooking pan and level the surface. The markings on the inside surface of cooking pan are for measuring the amount of water and are given in litres and cups. Add water to the corresponding level marked on the inner surface of the cooking pan as per the below table :

Quantity of water required for one cup of rice.

Required texture	Slightly under Cooked	Firm	Medium	Soft
Example	Chinese fried Rice	Pulao	Plain Rice	Khichadi Pongal
Water (in cups)	1 ¹ / ₂ -1 ³ / ₄	2	2 ¹ / ₄ -2 ¹ / ₂	3-4

4. Place the cooking pan in the cooker ensuring that there is no rice or any moisture on the outside of the bowl.

5. Cover with the lid, ensuring that the vent hole in the lid is situated away from you.

6. Plug in the detachable power cord into the cooker power socket and then connect to the power supply. The keep warm indicator will glow.

7. Press down the switch, the cooker will start. The cooking indicator will glow and the keep warm indicator will go off.

8. When the food is done, the main heater will turn off automatically. The cooking indicator will go off and the keep warm indicator will glow. During cooking it is normal for the lid to rise up slightly and water to bubble around the edge.

9. Carefully lift the lid and allow any condensation to drip into the cooker. Use the spatula to fluff up the rice which is then ready to serve. Replace the lid as quickly as possible. Consume the stirred rice within 1 hour.

- Food left to keep warm should be stirred occasionally otherwise it may burn and stick to bowl. The keep warm period should not exceed 2 hours.

10. Switch off at the mains and remove the detachable power cord. Remove the cooking pan to serve the food.

- Never take the cooking pan out of the cooker when it is filled with water.

Steaming

Fill the cooking pan with water to the 6 cups level. Place the steamer in the cooking pan and put the ingredients in. Put the lid on the steamer.

Switch ON the cooker. The cooking indicator illuminates, which means cooking function has started. The time required to

steam the food depends on type of food, recipe and personal preferences.

Unplug the cooker after use.

You can steam a variety of vegetables, as long as they are large enough not to fall through the holes of the steamer.

Tips for best cooking results

- Make sure that the rice or any other food is spread over the whole surface of the cooking pan to ensure even cooking.

- You may find that to suit your personal taste you need to slightly adjust the amount of water added. For a softer rice add a little more water, and a firmer rice a little less water.

- The cooking times may vary according to the quantity and type of rice or any other food.

- A thin crust of rice may form on the base, particularly when cooking Italian or easy cook type rice, or when cooking smaller quantities. Wiping half a teaspoon of oil over the base may help reduce this problem, but this occurrence is not always preventable.

Cleaning

Before cleaning and maintenance, switch the cooker off and unplug it.

1. Wash the cooking pan, steamer and lid in warm soapy water and dry well.

2. Wipe the main unit with a damp cloth. Do not use any abrasive or solvent-based cleaner.

- If food has stuck to the bottom, allow the cooking pan to soak for a while before washing it.

- Do not immerse the cooker in water, nor pour water into it.

- Ensure the area between the main unit and cooking pan is always clean and free from any rice or food particles etc. This is important to ensure proper contact between the two.

Important:

The brown marks and scratches that may appear after many hours of use are not a problem. We guarantee that the non-stick coating complies with the standards and regulations on materials suitable for contact with food.

Taking care of the cooking pan:

Use a plastic or wooden spoon and not a metal one so as to avoid damaging the surface.

Safety cut-out :

The cooker is fitted with a thermal fuse, which will cut off the power automatically in case of over heating. If this happens, the cooker must be brought to an authorised service center of Morphy Richards for repair.

Morphy Richards products are intended for household use only

Morphy Richards has a policy of continuous improvement in product quality and design. The Company, therefore, reserves the right to change the specification of its models at any time.

Products & parts are indicative only, the actual product may differ.

morphy richards

Morphy Richards Ltd, Mexborough,
South Yorkshire, England, S64 8AJ